

# REPLACEMENT SHEET

4/5

FIG.4




FIG.5

FLAG CDPWRF	FUNCTION	BROADCAST RECEIVING	CD/CASSETTE/ LINE INPUTS (MD)
"1"		ON	ON
"0"		ON	OFF

POWER CONTROL OF CD PLAYER